

# How To Pair Your Remote with ShadeMonster Motorized Shades

---

## Adding Remote Controls or Channels

- A) Press and Hold the Stop button on current remote/channel that controls the motor for 5 seconds. The motor will jog once.
- B) Select the new remote control or channel on the same remote control.
- C) Press the up button on the new remote/channel. The motor will jog once. The motor will now respond to all channels that have been added.

## Deleting Remote Controls or Channels

- A) Select the remote-control channel that you want to delete.
- B) Press and Hold the Stop button for 5 seconds. The motor will jog once.
- C) Press and Hold the program button on the back of the remote control for 1 second. The shade will jog. The channel has now been deleted.

## Resetting Motor Using the Motor Head

(4 short presses followed by a long press)

- A) Briefly Press the program button on the motor. The motor will beep.
- B) Briefly Press the program button on the motor. The motor will beep.
- C) Briefly Press the program button on the motor. The motor will beep.
- D) Briefly Press the program button on the motor. The motor will beep.
- E) Press and Hold the program button on the motor for 3 seconds. The motor will jog twice. A jog is a movement in both directions.

Note: The motor should not jog during the first 4 steps. You are holding the button too long if it does and the motor will not reset.

## How To Pair Your Remote with ShadeMonster Motorized Shades

### Resetting Motor Using a Remote Control

Put any other motors using the same channel to sleep or they will be reset.

A) Select the remote control or channel that controls the motor.

B) Press and Hold the Stop button for 5 seconds. The motor will jog once.

C) Within 10 seconds Press and Hold the program button on the back of the remote control for app. 7 seconds. The motor will jog once at 1 second and two more times at 7 seconds.