ROLLER SHADES WITH SQUARE CASSETTE INSTALLATION GUIDE

NO FEAR WE'RE HERE

ShadeMonster Window Treatments is here to help you every step of the way. Please follow our step by step guide to install your window treatments with ease.

SHADEMONSTER®

Installation Instructions

Note: It is best to read through the installation instruction completely prior to beginning your installation.

ROLLER SHADES WITH VALANCE PARTS

SHADEMONSTER.



A - End Cap
B - Mounting Bracket
C - Cassette headrail
D - Roller Tube
E - Clutch
F - Beaded Chain
G - Chain Tensioner
H - Hem Bar
I - End Plug

TOOLS THAT YOU WILL NEED


Cordless Drill

Tape Measure

Pencil

Step stool or ladder

Installation Steps

Important: Ensure the installation surface is completely level. Align all brackets in a straight, even line so the shade can move smoothly. If any bracket sits low, insert thin shims beneath it until every bracket is exactly level.

1. INSTALL THE BRACKETS

Measure and mark where the brackets will be placed. Brackets should be 1 ¼" in from each end of the cassette.



Inside Mount (IB): Position brackets at least ¾" back from the front edge of the window frame. Use a level to make sure brackets are aligned.
Secure each bracket with two 1 ¼" screws.



Outside Mount (OB): Position brackets so the top is level with the front edge of the window frame. Use a level to make sure brackets are aligned. Secure each bracket with two 1 ¼" screws.

2. ATTACH THE CASSETTE

1. Hook the front flange of the cassette onto the front lip of the brackets.
2. Rotate the cassette upward until the back flange snaps into the bracket.
3. Ensure the cassette is firmly locked in place.



Installation Steps

3. INSTALL THE CHAIN TENSIONER

Lastly, install the chain tensioner (J) to the inside of your window frame. Loop the beaded chain (I) through the opening of the tensioner to ensure that the chain is fastened.

4. TEST THE OPERATION

Once the roller shade (D) is secured into place, test the operation of the shade or blinds with the brackets, making sure they are level.

Removal (if needed)

1. Insert a flathead screwdriver between the top of the cassette and the bracket.

2. Pry gently to release the cassette from the bracket.

3. Remove shade carefully (especially if using 3 brackets—detach ends first, then the middle).



ENJOY YOUR NEW WINDOW TREATMENTS

Still need help? ShadeMonster can guide you through the process and answer any questions during installation. Set up a live chat and/or watch our installation videos to see how it's done.

Roller Shades Care

Vinyl and PVC Roller Shades

For a light dusting, use a feather duster or the brush attachment on a vacuum. Use mild soap and water on a damp cloth to wipe them down. Rinse thoroughly after cleaning and let them air dry.

Need something stronger than soap and water?

Before using other cleaners, test them in a small area to make sure they won't damage or leave spots or marks on your shades. Avoid strong cleaners and disinfectants, especially those containing quaternary ammonium compounds and phenols.

Fabric Roller Shades

Fabric roller shades should only be dusted, do not clean them with water.

CAUTION

Dangling window cords are dangerous to children and pets and are considered a strangulation hazard. If you have small children, you should ideally only use cordless window treatments. The Window Covering Safety Council recommends ONLY cordless window treatments in homes with small children. If your home has old window treatments, consider replacing them with safer options. Be absolutely certain that all window treatments are installed correctly, even cordless options. Children and pets may be able to reach lower areas of a window treatment and improperly installed or fastened blinds or shades could fall and seriously injure an adult or child.